

CONTENIDO

PARTS LIST

A 4x  **B** 4x 

C 4x  Distanciador
Spacer 13x17

4x  Distanciador
Spacer 18x23

D 4x  M8 x 18

4x  M6 x 12

4x  M6 x 35

4x  M5 x 12

4x  M5 x 30



4x  M4 x 12

*Si el tornillo es M4 es obligatorio
utilizar las arandelas E*

4x  M4 x 30


*If screw is M4, you must use
washer E*

E 4x  15x5.5x1.2



HERRAMIENTA NECESARIA(NO INCLUIDA)

TOOLS REQUIRED(NOT INCLUDED)



MONTAJE

INSTALLATION GUIDE

AX104

